

# CIRCLEAN PHOSPHATE FREE

## Tank & Line Cleaner

### → DESCRIPTION

A low-foaming non-caustic liquid used for CIP (Clean-in-Place) applications in the food and beverage industry.

### → BENEFITS

- Phosphate free
- Low-hazard product that is much safer than caustic-based cleaners
- Assists with tartrate removal
- Provides light de-staining of tanks and transfer lines
- Can be used for traditional tank cleaning where light to medium duty soils are present
- Can be used in recirculating systems
- Able to control dosage through conductivity
- Phosphate free formulation helps reduce the production of algal blooms in water ways and water treatment areas

### → APPLICATION

CirClean Phosphate Free is recommended for CIP cleaning and light de-staining of tanks and transfer lines.



### → DIRECTIONS FOR USE

#### TARTRATE SOILING

The amount of CirClean Phosphate Free required will depend on the level of soiling and the size of the tank. The thickness of the tartrate deposit can vary dependant on the age of the wine, type, how long it has been in the tank and process in use such as cold stabilisation. CirClean Phosphate Free is a cleaner not a sanitiser. If sanitising is required, sanitise tank using your preferred method.

#### TANK CLEANING

Use CirClean Phosphate Free at dilutions from 1L/100L (1% v/v) to 5L/100L (5% v/v) depending on the degree of soiling of cleaning fluid. Cleaning fluid is 1.5-2% of the tank size (eg. 10,000L tank will use 150-200L cleaning fluid). Circulate in CIP for 15-20 minutes then rinse with potable water.

#### RE-CIRCULATING SYSTEMS

Use CirClean Phosphate Free at dilutions from 2L/100L (2% v/v) to 4L/100L (4% v/v). For ongoing efficacy, ensure the pH of the circulating cleaning solution is greater than 10. Circulate in CIP for 15-20 minutes then rinse with potable water.

### → TECHNICAL INFO

Fragrance	Colour	Form	pH Level
No added fragrance	Straw	Liquid	10.8-11.4 at 1% w/w

### → AVAILABLE IN

Product	Code
15L Drum	C18778
1000L IBC	C10190



**Dominant**  
dominant.com.au

1300 789 852 enquiry@dominant.com.au



A Safety Data Sheet for this product can be found at [dominant.com.au](http://dominant.com.au) or use the QR code



SAFETY INFORMATION

RECOMMENDED PPE

24 Hour Medical Emergency Line 13 11 26