

MICRO SAN

Anti Microbial Laundry Liquid

→ DESCRIPTION

Micro San forms part of the Micro Active Laundry System. It features Protekta® Cap for safe connection to the Micro Active feeder.

→ BENEFITS

- Highly concentrated anti microbial laundry liquid for woollens and other fabrics.
- Contains a unique blend of detergents, sanitisers, water softeners and cleaning aids to assist in cleaning soiled fabric
- Use when linen cannot be thermally disinfected because of risk of fabric damage or washing machine cannot achieve the temperature required by Australian Standard AS4146
- When used as recommended at 40°C Micro San is proven to comply with Australian Standard AS4146. All bacteriological testing conducted by NATA registered analytical laboratory Merieux
- Non-hazardous and non-dangerous
- Automatically feeds directly to the washing machine at accurate dosage or can also be used in a domestic machine
- Featuring Dominant's proprietary Protekta® Cap, a no touch system ensuring staff are never exposed to the product
- Lightweight packaging with minimal bottle change over
- Wash discharge is always within water authority limits and safe for septic systems

→ APPLICATION

Micro San can be used in both domestic washing machines and also in commercial laundries through Dominant's Micro Active Laundry System.



→ TECHNICAL INFO

Fragrance	Colour	Form	pH Level
No Added Fragrance	Pale Brown	Liquid	10.0-11.0

→ AVAILABLE IN

Product	Code
2 x 5L with Protekta® Cap	C11533



→ DIRECTIONS FOR USE

DOMESTIC MACHINES

Micro San should be used at a rate of 30ml per 5kg wash load using a minimum 40°C cycle.

Washing Machine Capacity			
Machine Size	5kg	8kg	10kg
mL's per wash	30mL	48mL	60mL

COMMERCIAL LAUNDRY

Use in conjunction with Dominant's other Micro Active System products such as Micro Break, Oxy or Bleach for best results. Dispense using Dominant's Micro Active System Dispenser. This automatically feeds Micro San directly to the washing machine at accurate dosage.

Do not mix with Micro Suds or other laundry detergent as this will de-activate the sanitising ingredient.

Your Dominant Technical Representative will install and monitor the system to ensure compliant results every wash. To change bottles unscrew the pickup connector from the empty bottle, remove the cap from the new bottle and screw on pickup connector.

Dominant
dominant.com.au

E

QUATERNARY

A Safety Data Sheet for this product can be found at dominant.com.au or use the QR code



SAFETY INFORMATION

RECOMMENDED PPE